

Failure Mode Testing During Verification Identifies Mechanical Failure in an ABSL-3 Facility

Amy Helgerson, MS, RBP
Environmental Health and Safety
Iowa State University



Agenda

- Background
- Verification parameters
- Results
- Take home messages



Iowa State University 2013-2014



8,780 faculty & staff



33,241 students
27,659 undergraduates
4,996 graduate students
586 Vet Med students




1,984 acres
802.9 hectares

BSL-3 Experience

- Animal Biosafety Level 3 – Infectary
- Single laboratory BSL3/ABSL3
- Modular BSL-3/ABSL3
- ***Veterinary Diagnostic Laboratory***



The original 12 NAHLN laboratories



NAHLN- A State and Federal Partnership to Safeguard Animal Health

VS

Veterinary Services

Safeguarding Animal Health

July 2013



NAHLN Laboratory Requirements

1. Fully accredited by AAVLD or by an accrediting body to the OIE/ISO 17025 standard to cover the scope of NAHLN testing
2. Provides and maintains BSL3 laboratory space with sample handling, processing, and testing capacity.
- 3.
4. Shall provide train the trainer expertise, as requested
5. Competence, capability, and capacity for high-throughput testing
6. Active participation in electronic messaging of surveillance test results
7. Test data reported within time frames indicated in SOPs
8. Agrees to assist other laboratories to develop and implement IT capabilities
9. Shall accept samples from other states impacted by a disease outbreak
10. Provides funding associated with maintaining equipment and laboratory space used for NAHLN purposes

BMBL 5th


- Laboratory Facilities (Secondary Barriers)
 - 15 items to consider

'The (ABSL-3) facility must be tested to verify that the design and operational parameters have been met prior to use.'

'Facilities should be re-verified at least annually against these procedures as modified by operational experience.'



What we do?



Verification parameters

- Review of records (i.e. SOP, training, etc.)
- Physical inspection
- **Operational performance tests**
 - Mechanical operation
 - Containment



Micromanometers

- Differential pressure between spaces
- Placed in doorways between adjoining spaces
- Failure mode testing mirrored previous year




Sequence for Testing




Failure mode test

Total & Emergency Power




Failure mode test Exhaust Fans




Failure mode test

Supply Fan



Facility description




2,942 ft² ABSL-3

Ceiling Rail System




HVAC system





Magnehelic gauges





Planning, Design, Built


Commissioning &
Verify

Occupancy


Re-Verification




Baseline




Fail Exhaust Fan 1



Fail Exhaust Fan 2



Fail Both Exhaust Fans




Potential culprits

- Improper air valve settings
- Unsynchronized supply and exhaust
- Dry plumbing traps


Three failed verification attempts later...






Culprit....Air valves


- *Supposed* to close the duct to prevent or restrict airflow
- Actuated by small electric motors
- Constantly adjusted by BAS





Next time....

Fail EF-11A & EF-11B



Take home messages

- Failure mode testing is recommended
- Failure mode testing revealed mechanical deficiencies
- Equipment failure occurred even though the BAS indicated everything was functioning correctly

Steven Ziegenfuss

Jessica Boor

Leroy Brown

Steven Prater

Thanks!



Questions?

Ziegenfuss, S., Helgerson, A., Matos, B., Dombroski-Brokman, A.
Applied Biosafety, Vol. 18, No. 2, 2013

Adventure Safely!